
SMART REMOTE USER MANUAL


BUTTON SPECIFICATIONS



FIRST STEP

Power the lighting device off, then back on to enter pairing mode. Always complete this step before using the remote.

PAIRING REMOTE



To pair the remote, press and hold both the **'ALL and Add Device'** buttons together. The device will enter **pairing mode by blinking consecutively.**

Once, the blinking stops, the device has been paired.

USAGE

Power Button -
To turn the desired lighting device or group **ON or OFF,** press the **'POWER**' button.

Night Mode -
Pressing this button sets the lighting device(s) to 5% Warm White.

ALL

Control All Devices:
The **'ALL'** button allows you to control all connected devices at once.

Pairing the Remote:
To pair the remote with the device/s, press **'ALL + ADD DEVICE'** simultaneously.

Unpairing the Remote:
To unpair the remote with the device/s, press **'ALL + DELETE DEVICE'** simultaneously.

CHANGE BRIGHTNESS

Dimming-
To adjust the brightness of the devices, press **'Bright +'** or **'Bright -'** as per your convenience. It will function in **CCT** mode.

CCT CONTROL

CCT- & CCT+

In CCT mode, these buttons **adjust the color temperature**, transitioning from **warm white to cool white.**



Group Buttons -

To activate a group of devices, simply **press the corresponding Group button,** and the devices within that Group will turn on.



RGB Button -

Pressing this button allows you to shift between 12 preset colors.



Add Button -

1.Used for pairing devices with the remote.
2. Allows adding paired devices to a specific group for unified control.



Delete Button -

1.Used for removing devices with the remote.
2. Allows removing paired devices from a specific group.

DEVICE CONTROL



FUNCTIONS:

To control all devices at once, press the All button once and then use the following functions:

1. Power On/Off – Press Power to turn all devices on or off.
2. Night Mode – Press Night Mode to set all devices to 5% Warm White.
3. Brightness Control – Press Bright+ to increase brightness, or Bright- to decrease it.
4. CCT Control – Press CCT+ to shift towards Cool White, or CCT- to shift towards Warm White.
5. RGB Control – Press RGB to cycle through 12 preset colors.

ADDING/REMOVING DEVICES TO GROUP





FUNCTIONS:

To add devices to a group, press the desired group button (G1–G4) along with the Add Device button.
The selected device/s will then be assigned to that group.

Ensure only the lights you want to add are turned on, while others remain off.

To remove device/s from a group, press the desired group button (G1–G4) together with the Delete Device button.

The selected device/s will be removed from that group.

GROUP CONTROL



FUNCTIONS:

To control all devices in a group, press the desired group button (G1–G4) once, then use the following functions:

1. Power On/Off – Press Power to turn all device/s on or off.
2. Night Mode – Press Night Mode to set all device/s to 5% Warm White.
3. Brightness Control – Press Bright+ to increase brightness, or Bright- to decrease it.
4. CCT Control – Press CCT+ to shift towards Cool White, or CCT- to shift towards Warm White.
5. RGB Control – Press RGB to cycle through 12 preset colors.