
SMART REMOTE USER MANUAL

BUTTON SPECIFICATIONS



PAIRING REMOTE



To pair the remote, press and hold both the **'ALL and Power'** buttons together.

The remote will enter **pairing mode.**



Tap the **"+"** icon in the app to add a remote.

The app will scan for **nearby devices** and display an option to **add them.**

Select the **remote** from the list to complete the **pairing process.**

plexilent®
simplifying life

CONFIGURING GROUP KEYS ON THE REMOTE

Default Group Assignment:
The first four groups set in the app are automatically assigned to the group keys **G1, G2, G3, and G4** on the remote.

These keys will function for the first four groups from the app until **reconfigured.**

Accessing the Control Screen:
To configure the group keys, open the control screen for the remote in the app. **Long press** the icon of the newly added remote in the app to **access the control screen.**



Entering Configuring Mode:
After opening the control screen, press and hold both the **ALL and Power** buttons on the remote to **enter configuring mode.**

Assigning Group Keys:
Once the remote is in configuring mode, you can assign the group keys **(G1, G2, G3, G4)** to the groups of your preference for easy access.

USAGE



Power Button -
To turn the desired group **ON or OFF,** press the **'POWER'** button.



Using the Mode Button

Switch Between Modes:
Press the Mode button on the remote to **switch between RGB (color-changing mode) and CCT (white light temperature control mode).**

RGB Mode:
In RGB mode, you can adjust the colors to your preference.

CCT Mode:
In CCT mode, control the white light's temperature for warm or cool settings.



Control All Devices:
The **'ALL'** button allows you to control all connected devices at once.

Pairing the Remote:
To pair the remote with the app and devices, press **'ALL + ON'** simultaneously.

Unpairing the Remote:
To unpair the remote, press **'ALL + Mode'** simultaneously.

CHANGE BRIGHTNESS



Dimming-

To adjust the brightness of the devices, press **'Bright +'** or **'Bright -'** as per your convenience. It will function in both **'RGB & CCT'** mode.

DUAL CONTROL



CCT-/RGB- & CCT+/RGB+

When in RGB mode, the buttons cycle through different colors, allowing you to **change between various colors in the spectrum.**

In CCT mode, these buttons **adjust the color temperature**, transitioning from **warm white to cool white.**

LIGHT PRESET



Warm White, Cool White,and Neutral White Presets:
These preset buttons allow you to **instantly switch between warm white, cool white, and neutral white lighting,** adjusting the light's temperature to suit your preference or environment.



Group Buttons -

To activate a group of devices, simply **press the corresponding Group button,** and the devices within that Group will turn on.

MANUAL UNPAIR



Resetting/Unpairing The Remote
If you need to reset or unpair the remote from the app, follow these steps:

Ensure the Remote is On:
Make sure the remote is powered on before attempting to reset or unpair it.

Press the Reset Buttons:
Simultaneously press and hold both the **'ALL and Mode'** buttons on the remote.

Hold for a Few Seconds:
Keep holding both buttons for a few seconds until you see a notification on the remote **(such as a light flash)** indicating that it is resetting.

Remote is Reset:
Once the reset process is complete, the remote will return to its **default factory settings.**

Any previous pairings with the app will be erased, and the remote will need to be paired again before it can be used.

Re-pairing the Remote:
To use the remote again, follow the steps to pair it with the app as outlined in the "Pairing the Remote with the App" section.

UNPAIR VIA APP

Open the Control Screen:
Press and hold the **remote icon** in the app to open the **control screen.**



Enter Configuring Mode:
On the control screen, press and hold the **'ALL & POWER '** button on the remote to enter **configuring mode.**

Select Kickout in the App:
Once in configuring mode, tap the **'Kickout'** button in the app to **unpair** the remote.

Confirm Unpairing:
The **LED** on the remote will **blink 8 times** to confirm that the remote has been **successfully unpaired.**