
SMART REMOTE USER MANUAL

BUTTON SPECIFICATIONS



PAIRING REMOTE

PAIR

To pair the remote, press and hold the **'Pair'** button for **3-5 seconds.**

The remote will enter **pairing mode.**



Tap the **"+"** icon in the app to add a remote.

The app will scan for **nearby devices** and display an option to **add them.**

Select the **remote** from the list to complete the **pairing process.**

Power Button -
To turn the desired group **ON or OFF,** press the **'POWER'** button.

plexilent®
simplifying life

CONFIGURING GROUP KEYS ON THE REMOTE

Default Group Assignment:
The **first 9 groups** set in the app are automatically assigned to the group keys **G1, G2, G3, and G4** and so on, in the remote. These keys will function for the first nine groups from the app until **reconfigured.**

Accessing the Control Screen:
To configure the group keys, open the control screen for the remote in the app. **Long press** the icon of the newly added remote in the app to **access the control screen.**



Entering Configuring Mode:
After opening the control screen, press and hold both the **'Pair'** buttons on the remote to **enter configuring mode.**

Assigning Group Keys:
Once the remote is in configuring mode, you can assign the group keys **(1, 2, 3, 4 and so on)** to the groups of your preference for easy access.

USAGE



Control All Devices:
The **'ALL'** button allows you to control all connected devices at once.



Lock Button -
The lock button holds the current settings and **disables other function** keys.

Press it again to unlock and **regain full control** of the remote.

PRESET BRIGHTNESS



SET Brightness -
These buttons allow you to instantly set the brightness to **25%, 50%, 75%, or 100%** for quick adjustments.

CHANGE BRIGHTNESS

Dimming-
To adjust the brightness of the CCT intensity of the devices, press **'Bright +' or 'Bright -'** as per your convenience.

CHANGE COLOR TEMP

Tuning CCT –
To adjust the CCT color temperature, press the **"CCT+"** to increase or **"CCT-"** to decrease.

CHANGE COLOR

RGB– RGB+

Tune Color-
To switch between spectrum of colours press on the **"RGB+ & RGB-"**

MANUAL UNPAIR

PAIR

Press and hold the **'Power'** and **'Pair'** buttons on the remote.

Hold for a Few Seconds:
Keep holding the buttons for a few seconds until you see a notification on the remote **(such as a light flash)** indicating that it is unpairing.

Remote is Unpaired:
Once the unpairing process is complete, the remote will return to its default factory settings.
Any previous pairings with the app will be erased, and the remote will need to be paired again before it can be used.

UNPAIR VIA APP

Open the Control Screen:
Press and hold the remote icon in the app to open the control screen.



Enter Configuring Mode:
On the control screen, press and hold the 'UNPAIR' button on the remote to enter configuring mode.

Select Kickout in the App:
Once in configuring mode, tap the 'Kickout' button in the app to unpair the remote.

Confirm Unpairing:
The LED on the remote will blink 8 times to confirm that the remote has been successfully unpaired.